



## Concrete Repair Kit

Model #: Repair – (BA, CB, CN, SD, SL, SM, TS, VA)

**INSTALLER:** Leave these instructions with consumer.

**CONSUMER:** Retain for future reference.



### SUPPLIES IN KIT

- Latex Gloves (2 Pairs)
- Plastic Cups (2)
- Metal Strips (4)
- White Admix Liquid (1 Bottle)
- Color Grout Mix (1 Bottle)
- 220-Grit Sandpaper (1/4 Sheet)

### OPTIONAL EQUIPMENT

- Safety Glasses
- Cement Sealer

This kit is used for minor concrete repairs on American Fyre Designs products. **Actual color-matching results may vary depending on application.**

1. **Ensure that the unit is OFF and completely cool, and that the gas supply to the unit is turned OFF.**
2. Wear gloves before beginning repair.
3. Pour a small amount of color grout mix into a cup.
4. Add a small amount of white Admix liquid into the cup. Stir with a metal strip. For larger repairs, use a thick, toothpaste-like consistency. For small repairs or fine cracks, use a slightly more runny consistency. Add more color grout mix if needed.
5. Let the mixture sit for approximately 15 minutes before application.
6. Use the metal strip to apply mixture to the damaged area. Mold it to conform to the area's original shape. Repeat steps 3 and 4 if more mixture is needed.
7. Wait approximately 5 minutes. If necessary, gently pat the repaired area with a damp sponge or a soft cloth to smooth out the edges.
8. Allow to dry for 3 hours.
9. Use the sandpaper to lightly sand and smooth out the repaired area as needed.  
**Note:** Sanding the area will lighten the color of the grout.
10. It is recommended to apply cement sealer (not included) to seal the repair and preserve the finish.