



Wind Deflector

Model # (24,30,36)-B-24

INSTALLER: Leave these instructions with consumer.
CONSUMER: Retain for future reference.

This wind deflector is for use on AOG grills. To install, follow the steps below:

Ensure the grill is completely cool, the knobs are in the off position, the gas supply to your grill is turned off, and the power supply is disconnected (as applicable).

24" models

1. Open the oven lid and align the wind deflector on the top of the oven liner.
2. Insert the left side (A), the right side (B), then slightly shift right to center (C). See Fig. 1-1.




Fig. 1-1 Install 24" model

30/36" models

1. Open the oven lid and align the wind deflector on the top of the oven liner, centering it from left to right.
2. Carefully slide the the wind deflector into place, until the tabs lock the deflector in place. See Fig. 1-2.

Note: The wind deflector is designed for permanent installation.



Fig. 1-2 Install 30/36" model




Fig. 1-3 Side view detail